

An Update: 14 of the Newest Fiber-Optic Cables

E32

Solve More Application Problems With 14 of the Newest Fiber-Optic Cables

- Combine cables with Omron's fiber-optic amplifiers for a complete solution to your sensing application
- Over 80 other fiber-optic cable solutions available, refer to E32 data sheet in Omron's Sensing Products catalog



Ordering Information _____

■ FEATURES

Application	Features		Sensing method	Part number
Robotic applications with constant flexing and little installation space at the sensing	1.5 mm diameter sensing head, s		Through-beam	E32-T22B
site	4 mm bending radius for 90-degree prevents reduction in sensing dis		Diffuse	E32-D22B
	M4 threaded head, 4 mm bending	g radius	Diffuse	E32-D21B
Harsh environment applications requiring chemical-resistant sensing heads	Teflon [®] resin sheath protects fibe 5 mm diameter sensing heads fro cals, solvents and oils; side-view	m chemi-	Through-beam	E32-T14F
High-temperature sensing sites that also require chemical resistance	-40° to 150°C, side view sensing 2 mm diameter head for miniature detection		Through-beam	E32-T54
Area detection senses objects coming in	30 mm sensing area		Through-beam	E32-T16W
random positions anywhere within a wide beam, i.e., pill detection on a conveyor	11 mm sensing area, side view		Through-beam	E32-T16J
beam, i.e., pin detection on a conveyor	16 alternated light source/receive pairs over a 10.85 mm area, side		Diffuse	E32-D36P1
High-precision detection requires the same	M3 threaded head, 2 m cable len	gth	Diffuse, coaxial	E32-C31
operating position regardless of the direc- tion from which the target enters the detec-	M3 threaded head, 1 m cable len	gth	Diffuse, coaxial	E32-C41
tion area	2 mm dia. sensing head, standard	d fiber	Diffuse, coaxial	E32-C42
Minute object detection in severely space- constrained sensing sites	2 mm dia. sensing head with 0.5 15 mm probe detects objects as gold wire (0.01 mm dia.).		Diffuse	E32-D331
Precise position detection with background suppression for reflective surface objects,	Rugged aluminum square sensing head. When used in	Left side emitter	Convergent beam diffuse	E32-L56E1
i.e., positioning glass wafers, slides	pairs, eliminate mutual interference by ordering one of each.	Right side emitter		E32-L56E2

Note: Teflon is a registered trademark of the Dupont Company and the Mitsui Dupont Chemical Company for their fluoride resin.

■ ACCESSORIES (ORDER SEPARATELY)

Description	Applicable fiber-optic cables	Specification	Part number
Small spot lens adapters	Use with E32-D32 and E32-C42 fiber-optic cables	3.7 mm dia. lens	E39-F3A
	Use with E32-C31 and E32-C41 fiber-optic cables	3.7 mm dia. lens	E39-F3A-5
		4.8 mm dia. lens	E39-F3B
		3.7 mm dia. lens	E39-F3C

Sensing Distance with Fiber-optic Cables

■ THROUGH-BEAM FIBERS

: Long-distance mode : Standard mode : High-speed mode

- "Standard object" measurements were made with E3X-DA-N set to Standard mode. The size of standard object is the same as the
 fiber core diameter or the lens diameter for models with a lens.
- "Minimum sensing object" is shown in parentheses below the standard object. The minimum sensing object size was determined when the E3X-DA-N amplifier received light that exceeded a light incident value of 1000 (set to digital incident level display).

Indicates models that customers can cut to length for their application. Models without this mark are pre-cut by the factory to maintain their respective specifications.

The table specifies the sensing characteristics of each fiber when used with the following amplifiers:

Legend:

DAN-HS E3X-DA-N (Digital amplifier- high speed mode)

DAN-LD E3X-DA-N (Digital amplifier- long distance mode)

DAN-SM E3X-DA-N (Digital amplifier- standard distance mode)

■ THROUGH-BEAM, GENERAL PURPOSE TYPE

Application	Features	Appearance	Туре	Detection distance	Standard object (Min. detectable object: opaque)	Part number
Flexible,	Ideal for mounting	-	DAN-HS	80 mm	0.5-mm dia.	E32-T22B
resists breaking	on moving sections 4 mm bending radius	1.5 mm dia.	DAN-SM	200 mm	(0.01-mm dia.)	- eg
			DAN-LD	220 mm		

■ SPECIAL-PURPOSE THROUGH-BEAM FIBERS

Application	Features	Appearance	Туре	Detection distance	Standard object (Min. detectable object: opaque)	Part numbe	r			
Chemical resistant	Side view Teflon- covered *1; with- stands chemicals	covered *1; with-	DAN-HS	150 mm	3.0-mm dia. (0.01-mm dia.)	E32-T14F				
	and harsh environ- ments; Operating ambient		DAN-LD	400 mm						
	temperature: -30°C to 70°C (-22°F to 158°F)		DAN-SM	500 mm						
Heat resistant	esistant 150°C *2; Detects	150°C *2; Detects	150°C *2; Detects		2-mm dia	DAN-SM	80 mm	1.0-mm dia. (0.01-mm dia.)	E32-T54	els .
sheath material: fluororesin; Operating ambient temperature: -40°C to 150°C (-40°F to 302°F)	al: I I	DAN-LD	230 mm							
		DAN-SM	290 mm							
Area sensing	Detects in a 30-mm area			DAN-SM	660 mm	0.3-mm dia.*2	E32-T16W _e			
*3	30 mm	DAN-LD	1,800 mm							
		DAN-SM	2,300 mm							
	Side-view; suitable		DAN-SM	660 mm	0.2-mm dia.	E32-T16J				
	for applications with limited spatial depth	nited spatial depth	DAN-LD	1,800 mm			- (g			
	,	T 11 mm T	DAN-SM	2,300 mm						

Note: 1. Teflon is a registered trademark of the Dupont Company and the Mitsui Dupont Chemical Company for their fluoride resin.

- 2. For continuous operation, use the products within the temperature ranging from -40° C to 130° C (-40° F to 266° F)
- 3. These figures are for a sensing distance of 100 mm and for detecting over a 11-mm area, or 10-mm area for the E32-T16. (Figures for the diameter of sensing objects are in the still state.)

■ DIFFUSE FIBERS

: Long-distance mode : Standard mode : High-speed mode

- "Standard object" measurements were made with E3X-DA-N set to Standard mode.
- "Minimum sensing object" is shown in parentheses below the standard object. The values of the minimum sensing object were
 obtained at a distance where the smallest object (gold wire) can be sensed with the Diffuse Fiber Unit.
- The E3X-DA-N may continue to receive internal reflective light when it is set to the maximum sensitivity setting. In this case, set the amplifier to "two-point teaching with or without-object teaching."

Indicates models that customers can cut to length for their application. Models without this mark are pre-cut by the factory to maintain their respective specifications.

The table specifies the sensing characteristics of each fiber when used with the following amplifiers:

Legend:

DAN-HS E3X-DA-N (Digital amplifier- high speed mode)
DAN-LD E3X-DA-N (Digital amplifier- long distance mode)

DAN-SM E3X-DA-N (Digital amplifier- standard distance mode)

Application	Features	Appearance	Туре	Detection distance (Values measured using white paper)	Standard object (Min. sensing object)	Part number
Thin fiber	Minute object	detection (0.5-mm	DAN-HS	1 mm	25×25	E32-D331
	detection (0.5-mm		DAN-SM	3 mm	(0.01-mm dia.)	
			DAN-LD	4 mm		
Flexible	resists moving sections	moving sections M4 screw	DAN-HS	10 mm	100×100 (0.01-mm dia.)	E32-D21B
(resists breaking)			DAN-SM	70 mm		- 6
0,			DAN-LD	90 mm		
		4.5	DAN-HS	10 mm	50×50 (0.01-mm dia.)	E32-D22B
			DAN-SM	30 mm		
			DAN-LD	40 mm	1	

■ SPECIAL-PURPOSE DIFFUSE FIBERS

Application	Features	Appearance	Туре	Detection distance (Values measured using white paper)	Standard object (Min. sensing object)	Part number	
Coaxial	M3 coaxial; high- precision positioning	M3 screw	DAN-HS	25 mm	25×25 (0.01-mm dia.)	E32-C31	
	accuracy; possible to mount small-spot		DAN-SM	75 mm]`		
	lens (E39-F3A-5/ F3B/F3C)		DAN-LD	100 mm			
	M3 coaxial; high- precision positioning	M3 screw	DAN-HS	10 mm	50×50 (0.01-mm dia.)	E32-C41	
	accuracy; possible to mount small-spot lens (E39-F3A-5/ F3B/F3C) 2-mm dia. coaxial; high-precision positioning accuracy; possible to mount	accuracy; possible to		DAN-SM	35 mm	(0.0.7	
			DAN-LD	45 mm]		
			DAN-HS	10 mm	50×50 (0.01-mm dia.)	E32-C42	
			DAN-SM	35 mm]		
mm dia.) lens (E39-F3A)		DAN-LD	45 mm				
Area		П	DAN-HS	50 mm	300×300	E32-D36P1	
sensing over wide areas	rer wide areas	DAN-SM	150 mm	(0.01-mm dia.)	~		
		DAN-LD	200 mm]			
Conver- gent beam	Suitable for positioning crystal glass		DAN-SM	4 to 12 mm	100 × 100 mm Soda glass with 7% reflection factor	E32-L56E1 E32-L56E2	

Specifications _____

■ THROUGH-BEAM FIBER-OPTIC CABLES

Part number	Operating ambient temperature	Operating relative humidity	Permissible bending radius	Core material	Sheath material	Enclosure rating
E32-T14F	-40°C to 70°C (-40°F to 158°F) with no icing	35% to 85% with no condensation	40 mm	PMMA	Teflon [®] resin	IEC IP67
E32-T16J	-40°C to 70°C (-40°F to 158°F) with no icing		10 mm		PVC	IEC IP50
E32-T16W	-25°C to 55°C (-13°F to 131°F) with no icing		10 mm		PVC	IEC IP50
E32-T22B	-40°C to 70°C (-40°F to 158°F) with no icing		4 mm min.		PVC	IEC IP67
E32-T54	-40°C to 150°C (-40°F to 302°F) with no icing*		35 mm		Fluoride resin	IEC IP67

^{*}When used continuously between -40°C and 130°C (-40°F and 266°F)

■ DIFFUSE FIBER-OPTIC CABLES

Part number	Operating ambient temperature	Operating relative humidity	Permissible bending radius	Core material	Sheath material	Enclosure rating
E32-D21B	-40°C to 70°C (-40°F	35% to 85% with no	4 mm min.	PMMA	PVC	IEC IP67
E32-D22B	to 158°F) with no icing	condensation	4 mm min.			
E32-D331			25 mm		Polyethylene	IEC IP67
E32-D36P1			25 mm min.			_
E32-C31	-40°C to 70°C (-40°F to 158°F) with no icing		25 mm min.	1	PVC	IEC IP67
E32-C41			25 mm min.	1		
E32-C42			25 mm min.			
E32-L56E1	0°C to 70°C (32°F to	`	35 mm min.		Fluoride resin	IEC IP40
E32-L56E2	158°F) with no icing		35 mm min.			


Teflon is a registered trademark of the Dupont Company and the Mitsui Dupont Chemical Company for their fluoride resin.

Dimensions


Unit: mm (inch)

■ THROUGH-BEAM FIBER-OPTIC CABLES


E32-T14F



E32-T16J



E32-T16W




Unit: mm (inch)

E32-T22B




E32-T54




Note: Sensing head withstands temperatures to 150°C (302°F).
When used continuously, do not exceed 130°C (266°F).

■ DIFFUSE FIBER-OPTIC CABLES


E32-D21B




E32-D22B




E32-D331



E32-D36P1




E32-C31




Note: The fiber for the emitter is identified by a white line.


E32-C41




Unit: mm (inch)

E32-C42






E32-L56E2



Note: Insert the fiber with the label into the emitter side of the amplifier.

■ ACCESSORIES (ORDER SEPARATELY)


Small Spot Lens Unit E39-F3A



Material: Tube: Aluminum Optical lens: Optical glass

Note: E39-F3A is a Lens Unit for E32-C42 and E32-D32 cables.

Small Spot Lens Unit E39-F3A-5



Material: Tube: Aluminum Optical lens: Optical glass

Note: E39-F3A-5 is a Lens Unit for E32-C31 and E32-C41 cables.


Small Spot Lens Unit E39-F3B



Material:
Tube: Aluminum
Optical lens: Optical glass
0.5,

Note: E39-F3B is a Lens Unit for E32-C31 and E32-C41 cables.

Small Spot Lens Unit E39-F3C



Material: Tube: Aluminum Optical lens: Optical glass

Note: E39-F3C is a Lens Unit for E32-C31 and E32-C41 cables.

Installation

■ FIBER-OPTIC CABLES

Mounting

Tightening Force

The tightening force applied to the sensing head should be as follows:

Threaded Model Spring mounting clip Toothed washers Set screw (M 3 max.) Nuts (attachment)

Sensing head	Tightening torque
M3/M4 screw	0.78 N • m max.
M6 screw/ 6-mm dia. column	0.98 N • m max.
1.5-mm dia. column	0.2 N • m max.
2-mm dia./3-mm dia. column	0.29 N • m max.
E32-T12F 5-mm dia. Teflon model	0.78 N • m max.
E32-D12F 6-mm dia. Teflon model	
E32-T16	0.49 N • m max.
E32-L25A	0.78 N • m max.

Use a proper-sized wrench.




Fiber Connection and Disconnection

The E3X amplifier has a lock button. Connect or disconnect the fibers to or from the E3X amplifier using the following procedures:

Connection


Remove the protective cover, insert the fiber into the amplifier, and lower the lock button until a click is heard.



After cutting the fiber using the E39-F4 Fiber Cutter, put an insertion mark on the fiber as a guide for correct insertion into the amplifier, and then insert the fiber up to this mark.

2. Disconnection

Remove the protective cover and raise the lock button to pull out the fiber.



Note: Remove the protective cover and raise the lock lever to pull out the fiber. (Before removing the fiber, be sure to confirm that the lock is released so as to maintain the fiber properties.)


3. Precautions for Fiber Connection/Disconnection

Be sure to lock or unlock the lock button within an ambient temperature range between -10°C and 40°C.


■ FIBER INSERTION

Make sure that the fiber is fully inserted in the amplifier. The sensing distance may decrease if the fiber is not fully inserted.


Standard 2.2-mm dia. Fiber



Thin Fiber with the E39-F9 Attachment



Fiber with Fixed Length




■ CUTTING FIBER

Insert a fiber into the Fiber Cutter and determine the length of the fiber to be cut.


Press down the Fiber Cutter in a single stroke to cut the fiber.

An insertion mark can be placed on the fiber to serve as a reference when inserting the fiber into the amplifier. Use the following procedure.

Confirm through the cutter hole that the fiber is inserted beyond the insertion mark hole so that the insertion mark is properly indicated, and then press firmly down on the cutter.




Insert the fiber into the amplifier up to the insertion mark. Proper fiber performance will not be achieved unless the fiber is inserted all the way to the insertion mark. (This method is applicable to standard, 2.2-mm-dia. fibers only.)



The cutting holes cannot be used twice. If the same hole is used twice, the cutting face of the fiber will be rough and the sensing distance will be reduced. Always use a new hole.

Use either one of the two holes on the right (refer to the following figure) to cut a thin fiber as follows:


 An attachment is temporarily fitted to a thin fiber before shipment.



Secure the attachment after adjusting the position of the thin fiber in the direction indicated by the arrow.



3. Insert the fiber to be cut into the E39-F4.



4. Finished state (proper cutting state)



Note: Insert the fiber in the direction indicated by the arrow.


Connection

Do not pull or press the fiber units. The fiber units have a withstand force of 9.8 N to 29.4 N (pay utmost attention because the fibers are thin).

Do not bend the fiber unit beyond the permissible bending radius.

Do not bend the edge of the fiber units (excluding the E32-T \square R and E32-D \square R).

Correct




Incorrect



Note: Do not apply excess force on Fiber units.


Correct



Incorrect



Excessive vibration can break the fiber head. Use the following method to prevent fiber head breakage.



E39-F32 ☐ Protective Spiral Tubes


Insert a fiber to the protective spiral tube from the head connector side (screwed) of the tube.




Push the fiber into the protective spiral tube. The tube should be straight so that the fiber is not twisted when inserted. Then turn the end cap of the spiral tube.



Secure the protective spiral tube on a suitable place with the attached nut.




Use the attached saddle to secure the end cap of the protective spiral tube. To secure the protective spiral tube at a position other than the end cap, apply tape to the tube so that the portion becomes thicker in diameter.



E39-F10 Fiber Connector

Mount the fiber connector as shown in the following illustrations



Each fiber unit should be as close as possible before they are connected.

Sensing distance will be reduced by approximately 25% when fibers are connected.

Only 2.2-mm-dia. fibers can be connected.

NOTE: DIMENSIONS SHOWN ARE IN MILLIMETERS. To convert millimeters to inches divide by 25.4.

OMRON ®

OMRON ELECTRONICS LLCOne East Commerce Drive

Schaumburg, IL 60173 1-800-55-OMRON **OMRON ON-LINE**

Global - http://www.omron.com USA - http://www.omron.com/oei Canada - http://www.omron.com/oci OMRON CANADA, INC. 885 Milner Avenue Scarborough, Ontario M1B 5V8

416-286-6465