LT135A

Hall Voltage 240mV GaAs Hall Device

■ Features

- Small temperature coefficient of the Hall voltage
- Good linearity of the Hall voltage
- Small imbalanced voltage
- Directly DC voltage applicable

■ Applications

- Brushless motors
  VCR, CD, CD-ROM, FDD
- Measuring equipment
  Gauss meters, magnetic substance detectors
- Noncontact sensors
  Microswitches, tape-end detection
- Other magnetic detection

■ Outline Dimensions

(Unit : mm)



As for dimensions of tape-packaged products, refer to page 44 .

■ Absolute Maximum Ratings

(T_a=25˚C)

Parameter	Symbol	Rating	Unit
Control voltage	V_C	12	V
Control current	I_C	15	mA
Power dissipation	P_D	150	mW
Operating temperature	T_{opr}	-20 to +125	˚C
Storage temperature	T_{stg}	-55 to +150	˚C
Soldering temperature*1	T_{sol}	260	˚C

*1 Soldering time : 10 seconds

■ Electrical Characteristics

(T_a=25˚C)

Parameter	Symbol	Conditions	MIN	TYP.	MAX.	Unit
No-load Hall voltage *1	V_H	V_C=6V, B=100mT	200	240	280	mV
Imbalanced voltage *2	V_{HO}	V_C=6V, B=0mT	-15	-	15	mV
Input resistance	R_{IN}	I_M=1mA, B=0mT	650	800	950	Ω
Output resistance	R_{OUT}	I_M=1mA, B=0mT	1 300	1 600	1 900	Ω
Drift of imbalanced voltage vs. temperature	$\|\Delta V_{HO}\|$	V_C=6V, B=0mT, T_a=-20˚C to 25˚C V_C=6V, B=0mT, T_a=25˚C to 125˚C	-	5	-	mV
Temperature coefficient of Hall voltage	β	I_C=6mA, B=100mT, T_1=-20˚C, T_2=125˚C	-	-0.03	-	%/˚C
Temperature coefficient of input resistance	α	I_M=1mA, B=0mT, T_1=-20˚C, T_2=125˚C	-	0.2	-	%/˚C
Linearity of Hall voltage	γ	I_C=6mA, B_1=50mT, B_2=100mT	-	2	-	%

*1 No-load Hall voltage is nearly proportional to Vc (within the range of 1 to 6V) at temperatures of -20˚C to + 125˚C.
Keep the voltage within the allowable power dissipation range.

*2 Imbalanced ratio is in +/-12% within the range of Vc=1 to 6V.

$V_H = V_M - V_{HO}$

$$\beta = \frac{1}{V_H(T_1)} \times \frac{\{V_H(T_2)-V_H(T_1)\}}{(T_2-T_1)} \times 100$$

V_M:Observed Hall voltage

$$\alpha = \frac{1}{R_{IN}(T_1)} \times \frac{\{R_{IN}(T_2)-R_{IN}(T_1)\}}{(T_2-T_1)} \times 100$$

V_{HO}:Imbalanced voltage

$$\gamma = \frac{\{K_H(B_2)-K_H(B_1)\}}{\{K_H(B_1)+K_H(B_2)\}} \times 2 \times 100, \quad K_H = \frac{V_H}{(I_C \times B)}$$

K_H:Sensitivity

Fig. 1 Hall Voltage vs. Ambient Temperature



Fig. 2 Input Resistance vs. Ambient Temperature



Fig. 3 Hall Voltage vs. Magnetic Flux Density



Fig. 4 Hall Voltage vs. Control Current



Fig. 5 Hall Voltage vs. Control Voltage



Fig. 6 Power Dissipation vs. Ambient Temperature