

# Energy Management Power Analyzer Type WM1-DIN

CARLO GAVAZZI



- 3-dgt multi-range  $\mu$ P-based meter
- Scrolling of power, energy, power factor ( $\cos \phi$ ), current and voltage
- Automatic selection of k (kilo) or M (mega) scale
- Automatic measurement of peak value
- Double measuring input: Up to 5 A or up to 27 A
- Degree of protection (front): IP 40
- Options:
  - Programmable alarm setpoint output
  - Pulse output for connection to remote display or PLC
  - Serial RS 485 output for connection to a personal computer

## Product Description

3-dgt  $\mu$ P-based meter for measuring power, energy, power factor ( $\cos \phi$ ), current and voltage with automatic selection of scale. A programmable alarm setpoint

output is available on request. The housing is easy to mount on DIN-rail and offers a degree of protection (front) of IP 40.

## Ordering Key WM1-DIN27AAD0XX

Model \_\_\_\_\_  
 Range code \_\_\_\_\_  
 Measurement \_\_\_\_\_  
 Power supply \_\_\_\_\_  
 Setpoints \_\_\_\_\_  
 Option \_\_\_\_\_

## Type Selection

Range code	Power Supply	Options	
<b>27A:</b> 5 AAC or 27 AAC selectable	<b>C:</b> 115 VAC, -15% +10%, 50/60 Hz <sup>1)</sup> <b>D:</b> 230 VAC, -15% +10%, 50/60 Hz (standard)	<b>XX:</b> None (1-phase/3-phase system with neutral, balanced load) <b>TX:</b> Measurement on 3-phase system without neutral (balanced load) <b>PX:</b> Pulse output (available only without alarm)	<b>RX:</b> RS 485 serial interface (1-phase/3-phase system, with neutral and balanced load) <b>SX:</b> RS 485 serial interface (3-phase system, without neutral and with balanced load)
	<b>Set-points</b> <b>0:</b> no alarm <b>1:</b> one alarm		

<sup>1)</sup> on request

## Input Specifications

<b>Accuracy</b> (@ 25°C $\pm$ 5°C, R.H. $\leq$ 60%) <b>Temperature drift</b> <b>Display</b> <b>Decimal point position</b> <b>Max. and min. indication</b> <b>Overflow indication</b> <b>Input</b> Current  Voltage (48 to 62 Hz)	$\pm 2\%$ f.s., $\pm 2$ dgt $\pm 250$ ppm/°C, 7-segment LED, h 14.2 mm, 3 digits Automatic selection and indication of "k" or "M" range. Max.: 999, Min.: 0 "oF" 27 AAC permanent, direct conn. max. 32 AAC for 2 minutes. 5 AAC permanent, CT conn. max. 6 AAC for 2 minutes 400 VAC (1-phase conn.) 500 VAC (3-phase conn.)	<b>Input (cont.)</b> Type  Wave form  Impedance Voltmeter input: Ammeter input:  <b>Key-pad enable input</b>	1-phase/3-phase with neutral, balanced load (standard) 3-phase without neutral, balanced load (on request) Undistorted sine wave (form factor 1.11)  $\geq 1$ M $\Omega$ 1 m $\Omega$ (27 A) 6 m $\Omega$ (5 A)  By means of external, voltage free NC contact. The input is not insulated from the measuring inputs. Can be used to avoid unwanted programming modifications, resets and totalized energy.
--	--	---	--

## Input Specifications (cont.)

<b>Measurements</b> Voltage, current, instantaneous power	$V_{L-N}$ , or $V_{L-L}$ , I, W, VA, VAR (max. display: 999M-) Accessible by means of the key-pad in run mode.
Peak value	Wh, VAh VARh (max. display: 999 M-) Accuracy: $\pm 4$ dgt @ 25°C, voltage $\geq 3\%$ f.s. current $\geq 10\%$ f.s.
Energy	Display: L.10/1.00/C.10; In case of voltage and/or current lower than 3% f.s., the display flashes "1.00"
Power factor - $\cos \varphi$	
<b>Reset date updating</b>	Month and day of the last reset manually programmed by key-pad
<b>Primary range</b>	Transformer ratio program- mable from 1 to 999 (max. 5000/5A).

## General Specifications

<b>Operating temperature</b>	0° to 50°C (32° to 122°F) (R.H. < 90% non-condensing)
<b>Storage temperature</b>	-10° to 60°C (14° to 140°F) (R.H. < 90% non-condensing)
<b>Insulation reference voltage</b>	300 V <sub>ms</sub> to ground
<b>Dielectric strength</b>	4000 V <sub>ms</sub> for 1 minute
<b>EMC</b>	EN 50081-1, EN 50082-1
<b>Safety standards</b>	EN 61010-1, IEC 61010-1, VDE 0411
<b>Connector</b>	Screw-type
<b>Housing</b> Dimensions	89 x 71.5 x 58.5 mm (4 DIN-modules)
Material	ABS, self-extinguishing: UL 94 V-0
<b>Degree of protection</b>	IP 40 (front)
<b>Weight</b>	Approx 320 g
<b>Approvals</b>	CE


## Output Specifications

<b>Alarms</b> (on request) Number of setpoints Setpoint adjustment	0 standard (1 on request). From 0 to 999 MW/MVA/ MVAR/instantaneous power, MWh/MVAh/MVARh energy and from L/C. 10 to 1.00 $\cos \varphi$ key-pad program- mable	<b>Serial output</b> (on request) Type	One-way multidrop RS 485 (double direction: only for standard static TRIAC output) 256 addresses key-pad selectable.
Accuracy	$\pm 2\%$	Addresses	W, VA, VAR, Wh, VAh, VARh, V, I, $\cos \varphi$ and setpoint status where present
Hysteresis	0 to 100% f.s. key-pad programmable	Data	1 start bit - 7 data bit - even parity - 1 stop bit.
Time delay adjustment	0 to 255 s key-pad programmable	Data format	1 start bit - 7 data bit - odd parity - 1 stop bit.
Alarm type	Low or high key-pad programmable	Baud-rate	1 start bit - 8 data bit - no parity - 1 stop bit
Output type	Static by TRIAC. (24 VAC to 250 VAC/max. 50 mA).	Connections	1200, 2400, 4800 and 9600 bauds, key-pad selectable
Insulation	2 kV between alarm output and all inputs and serial out - put (if available)	Power supply	2 wires (max. length: 1200 m) + shield. Bias and/or line termination (selectable by DIP-switch).
<b>Pulse output</b> (on request) Type	$V_{ON} = 0.6$ VDC/max. 4 mA $V_{OFF}$ max. 20 VDC	Insulation	Separate 5 VDC, power consumption 70 mA (PSU- DIN module).
Insulated, open collector:	ON status 200 ms OFF status 800 ms min.- NPN output		By means of optocouplers, 2 kV between serial output and measuring inputs.
Pulse:	From 1 to 999 pulses for kWh, kVAh or kVARh		2 kV between 5 VDC power supply input and measuring inputs.
Pulse number	2 kV between output and all inputs and serial output if available		
Insulation			


## Supply Specifications

AC supply	230 VAC, -15%+10%, 50/60 Hz (standard), 115 VAC, -15%+10%, 50/60 Hz (on request)
Insulation	4 kV between measuring inputs and power supply input 4 kV between enable input and power supply input
Power consumption	2.5 VA

## Dimensions (mm)



## Front Panel Description



### 1. Key-pad

- « S » Set/enter
- « ▲ » Up
- « ▼ » Down
- « Reset » Special function

Set-up and programming procedures are easily controlled by the 4 pushbuttons.

### 1. Key-pad (cont.)

“S”

- To enter programming.

“UP/DOWN” (into the programming procedure)

- To select: priority measurement, serial interface parameters or pulse output parameters (on request), maximum power, energy or cos  $\varphi$  (on request).

“UP/DOWN” (during measurement)

- Scrolling all the available measurements

“Reset”

- Reset the displayed value (totalized energy or peak value).

### 2. Display

3-digit (maximum read-out 999).

Alphanumeric indication by means of 7-segment display for:


- Displaying of the measured value.
- Indication of programming parameters.

### 3. LED


To display the selected engineering unit (flashing LED to notify an alarm activation).

## Wiring Diagrams


Direct connection on single phase or three-phase system with neutral and balanced load




CT connection on single phase or three-phase system with neutral and balanced load



Direct connection on three-phase system without neutral and with balanced load



CT connection on three-phase system without neutral and with balanced load



- (\*) An external 5 VDC power supply must be connected to the RS485 serial interface output (see PSU-DIN module)
- (◊) Attention: CT's cannot be earthed
- (●) Attention: The ENABLE input (KEY-PAD enabling) is not insulated from the measuring inputs
- (#) The static ALARM OUTPUT must be connected in series to the load to be controlled, as if it were a simple contact

## Network Connection

PC/WM1-DIN network connections (RS485 interface)

