

Short Barrel Inductive Prox

E2E 2-WIRE DC









Reduce Wiring to Control Devices with
Short-Barrel 2-Wire DC
Prox Sensors

- Thick nickel-plated brass barrel has wrench flats for easy installation
- Solid potted internal circuitry withstands shocks and water washdown to IP67
- High visibility indicator
- Choose prewired or connector models



Ordering Information











■ PREWIRED SENSORS

Self-diagnostic output function	Type	Size	Sensing distance	Part number	
				NO (Note.)	NC
Yes	Shielded 	M12	 3 mm	E2E-X3D1S	---
		M18	 7 mm	E2E-X7D1S	---
		M30	 10 mm	E2E-X10D1S	---
	Unshielded 	M12	 8 mm	E2E-X8MD1S	---
		M18	 14 mm	E2E-X14MD1S	---
		M30	 20 mm	E2E-X20MD1S	---

Note: A different oscillating frequency is available. Add a "5" to the part number (e.g., E2E-X3D15).

(This table continues on the next page.)














Ordering Information - continued from previous page

Self-diagnostic output function	Type	Size	Sensing distance	Part number	
				NO (Notes 1, 2.)	NC
No	Shielded 	M8	 2 mm	E2E-X2D1□	E2E-X2D2□
		M12	 3 mm	E2E-X3D1	E2E-X3D2
		M18	 7 mm	E2E-X7D1	E2E-X7D2
		M30	 10 mm	E2E-X10D1□	E2E-X10D2□
	Unshielded 	M8	 4 mm	E2E-X4MD1	E2E-X4MD2
		M12	 8 mm	E2E-X8MD1	E2E-X8MD2□
		M18	 14 mm	E2E-X14MD1	E2E-X14MD2
		M30	 20 mm	E2E-X20MD1	E2E-X20MD2

Note: 1. A different oscillating frequency is available. Add a "5" to the part number [e.g., E2E-X3D15].

2. E2E sensors with robotic cable are available. Add a "R" to the part number [e.g., E2E-X3D1-R].

■ SENSORS WITH BUILT-IN CONNECTOR

Connector size	Self-diagnostic output function	Type	Size	Sensing distance	Part number	
					NO (Pins 1 and 4)	NC (Pins 1 and 2)
M12/Micro Change®	Yes	Shielded 	M12	 3 mm	E2E-X3D1S-M1□	---
			M18	 7 mm	E2E-X7D1S-M1□	---
			M30	 10 mm	E2E-X10D1S-M1	---
		Unshielded 	M12	 8 mm	E2E-X8MD1S-M1	---
			M18	 14 mm	E2E-X14MD1S-M1	---
			M30	 20 mm	E2E-X20MD1S-M1	---
	No	Shielded 	M8	 2 mm	E2E-X2D1-M1G□	E2E-X2D2-M1G□
			M12	 3 mm	E2E-X3D1-M1G (See Note 1.)	E2E-X3D2-M1G□
			M18	 7 mm	E2E-X7D1-M1G□ (See Note 1.)	E2E-X7D2-M1G
			M30	 10 mm	E2E-X10D1-M1G (See Note 1.)	E2E-X10D2-M1G










Note: 1. A different oscillating frequency is available. Add a "5" to the part number [e.g., E2E-X3D15].

2. E2E sensors with a "G" in the part number denotes alternate pin arrangement. Refer to the *Connections* section.

3. Connector cordsets: For MicroChange® use OMRON Y96E-44□□; for NanoChange® use Omron XS3F-M42□-40□-R.

(This table continues on the next page.)

Ordering Information - continued from previous page









Connector size	Self-diagnostic output function	Type	Size	Sensing distance	Part number	
					NO (Pins 1 and 4)	NC (Pins 1 and 2)
M12/Micro Change®	No	Unshielded 	M8	 4 mm	E2E-X4MD1-M1G	E2E-X4MD2-M1G
			M12	 8 mm	E2E-X8MD1-M1G (See Note 1.)	E2E-X8MD2-M1G
			M18	 14 mm	E2E-X14MD1-M1G (See Note 1.)	E2E-X14MD2-M1G
			M30	 20 mm	E2E-X20MD1-M1G (See Note 1.)	E2E-X20MD2-M1G
M8/Nano Change®	No	Shielded 	M8	 2 mm	E2E-X2D1-M3G	E2E-X2D2-M3G
		Unshielded 		 4 mm	E2E-X4MD1-M3G	E2E-X4MD2-M3G

Note: 1. A different oscillating frequency is available. Add a "5" to the part number (e.g., E2E-X3D15).

2. E2E sensors with a "G" in the part number denotes alternate pin arrangement. Refer to the *Connections* section.

3. Connector cordsets: For MicroChange® use OMRON Y96E-44□□□; for NanoChange® use Omron XS3F-M42□-40□-R.











■ SENSOR WITH PIGTAIL CONNECTOR

Type	Size	Sensing distance	Polarity	Part number
				NO
Shielded 	M12	 3 mm	Yes	E2E-X3D1-M1GJ
			No	E2E-X3D1-M1J-T
	M18	 7 mm	Yes	E2E-X7D1-M1GJ
			No	E2E-X7D1-M1J-T
	M30	 10 mm	Yes	E2E-X10D1-M1GJ
			No	E2E-X10D1-M1J-T
Unshielded 	M12	 8 mm	Yes	E2E-X8MD1-M1GJ
	M18	 14 mm		E2E-X14MD1-M1GJ
	M30	 20 mm		E2E-X20MD1-M1GJ

Note: 1. A model with no polarity has a residual voltage of 5 V, which must be taken into consideration together with the interface condition (the PLC's ON voltage, for example) when connecting the proximity sensor to a load.

2. Connector cordsets: Use OMRON Y96E-44□□□.

■ SENSOR WITH FOUR-PIN CONNECTOR

Type	Size	Sensing distance	Part number	
			NO (Pins 3 and 4)	NC (Pins 2 and 3)
Shielded 	M8	 2 mm	E2E-X2D1-M1	E2E-X2D2-M1
	M12	 3 mm	E2E-X3D1-M1	E2E-X3D2-M1
	M18	 7 mm	E2E-X7D1-M1	E2E-X7D2-M1
	M30	 10 mm	E2E-X10D1-M1	E2E-X10D2-M1
Unshielded 	M8	 4 mm	E2E-X4MD1-M1	E2E-X4MD2-M1
	M12	 8 mm	E2E-X8MD1-M1	E2E-X8MD2-M1
	M18	 14 mm	E2E-X14MD1-M1	E2E-X14MD2-M1
	M30	 20 mm	E2E-X20MD1-M1	E2E-X20MD2-M1

■ ACCESSORIES

Description		Part number
Mounting brackets	Fits M8 size sensors	Y92E-B8
	Fits M12 size sensors	Y92E-B12
	Fits M18 size sensors	Y92E-B18
	Fits M30 size sensors	Y92E-B30
Silicone rubber covers for shielded sensors	Fits M12 size sensors	Y92E-E12-2
	Fits M18 size sensors	Y92E-E18-2
	Fits M30 size sensors	Y92E-E30-2
Connector cordsets		See Y96E and XS Connector Cordsets data sheets for details

Note: Use OMRON Y96E-44□□ cordsets with M12 connector; use XS3F cordsets with M8 connector.

■ REPLACEMENT PARTS

Description		Part number
Mounting hardware including one pair of metal nuts and one washer	Fits M8 size sensors	M8-MHWS
	Fits M12 size sensors	M12-MHWS
	Fits M18 size sensors	M18-MHWS
	Fits M30 size sensors	M30-MHWS

Specifications

■ RATINGS/CHARACTERISTICS

Part number		E2E-X2D□	E2E-X4MD□	E2E-X3D□	E2E-X8MD□	E2E-X7D□	E2E-X14MD□	E2E-X10D□	E2E-X20MD□
Size		M8		M12		M18		M30	
Type		Shielded	Unshielded	Shielded	Unshielded	Shielded	Unshielded	Shielded	Unshielded
Sensing distance		2 mm (0.08 in) ±10%	4 mm (0.16 in) ±10%	3 mm (0.12 in) ±10%	8 mm (0.31 in) ±10%	7 mm (0.28 in) ±10%	14 mm (0.55 in) ±10%	10 mm (0.39 in) ±10%	20 mm (0.79 in) ±10%
Supply voltage (operating voltage)		12 to 24 VDC, ripple (p-p): 10% max., (10 to 30 VDC)							
Leakage current		0.8 mA max.							
Sensing object		Magnetic metals (refer to <i>Engineering Data</i> for non-magnetic metals)							
Setting distance		0 to 1.6 mm (0 to 0.06 in)	0 to 3.2 mm (0 to 0.13 in)	0 to 2.4 mm (0 to 0.09 in)	0 to 6.4 mm (0 to 0.25 in)	0 to 5.6 mm (0 to 0.22 in)	0 to 11.2 mm (0 to 0.44 in)	0 to 8.0 mm (0 to 0.31 in)	0 to 16.0 mm (0 to 0.63 in)
Standard object (mild steel)		8 x 8 x 1 mm (0.31 x 0.31 x 0.04 in)	20 x 20 x 1 mm (0.79 x 0.79 x 0.04 in)	12 x 12 x 1 mm (0.47 x 0.47 x 0.04 in)	30 x 30 x 1 mm (1.18 x 1.18 x 0.04 in)	18 x 18 x 1 mm (0.71 x 0.71 x 0.04 in)	30 x 30 x 1 mm (1.18 x 1.18 x 0.04 in)	30 x 30 x 1 mm (1.18 x 1.18 x 0.04 in)	54 x 54 x 1 mm (2.13 x 2.13 x 0.04 in)
Differential travel		15% max. of sensing distance			10% max. of sensing distance				
Response frequency		1.5 kHz	1.0 kHz	1.0 kHz	0.8 kHz	0.5 kHz	0.4 kHz	0.4 kHz	0.1 kHz
Operation (with target object approaching)		D1 models: Load ON D2 models: Load OFF							
Control output (switching capacity)		3 to 100 mA (5 to 100 mA with residual voltage of 5V for -M1J-T models) Diagnostic output: 50 mA for -D1S models							
Diagnostic output delay		0.3 to 1 s							
Circuit protection		Surge absorber, load short-circuit protection (for control and diagnostic output)							
Indicator		D1 models: Operation indicator (red LED), operation set indicator (green LED) D2 models: Operation indicator (red LED)							
Ambient temperature		Operating: -25°C to 70°C (-13°F to 158°F) with no icing							
Ambient humidity		Operating: 35% to 95%							
Temperature influence		±15% max. of sensing distance at 23°C in temperature range of -25°C to 70°C (-13°F to 158°F)		±10% max. of sensing distance at 23°C in temperature range of -25°C to 70°C (-13°F to 158°F)					
Voltage influence		±1% max. of sensing distance in rated voltage range ±15%							
Residual voltage		3.0 V max. (under load current of 100 mA with cable length of 2 m) 5.0 V min. for -M1J-T models							
Insulation resistance		50 MΩ min. (at 500 VDC) between current carry parts and case							
Dielectric strength		1,000 VAC for 1 min between current carry parts and case							
Vibration resistance		10 to 55 Hz, 1.5-mm double amplitude for 10 times each in X, Y, and Z axes							
Shock resistance		500 m/s ² (approx. 50G) for 10 times each in X, Y, and Z axes		1,000 m/s ² (approx. 100G) for 10 times each in X, Y, and Z axes					
Enclosure rating	IEC	IP67							
	NEMA	1, 4, 6, 12, 13							
Weight		Approx. 45 g		Approx. 120 g		Approx. 160 g		Approx. 220 g	
Material	Body	Stainless steel		Brass					
	Sensing face	PBT							


Operation

■ OUTPUT CIRCUITS

E2E-X□D□DC 2-Wire Models


E2E-X□D□

Without Diagnostic Output



E2E-X□D1-M1J-T


No Polarity



- Note:
1. The load can be connected to either the +V or 0-V side.
 2. The E2E-X□D1-M1J-T has no polarity. Therefore, terminals 3 and 4 have no polarity.

E2E-X□D1S□

With Diagnostic Output



Short-Circuit Indication

The LED dims when the load is shorted and the load output immediately turns off and remains off until the short-circuit protection is reset.

Resetting Short-Circuit Protection

Before the short-circuit protection can be reset, the short must be repaired. We recommend turning the power off before repairing the short. If this approach is taken, no further action is required to reset the short-circuit protection.

If the short must be repaired with power on, the following resetting steps are required:


For NO sensors, the target must be removed to reset the short-circuit protection.

For NC sensors, the target must be presented then removed to reset the short-circuit protection.

■ OPERATING CHARTS


E2E□X□D1

NO Type




E2E□X□D2

NC Type



E2E□X□D1S




Note: The diagnostic output of the E2E□X□D1S is ON when there is a coil burnout or the sensing object is located in the unstable sensing range for 0.3 s or more.

Engineering Data

■ OPERATING RANGE (TYPICAL)


Shielded Models

E2E□X□D□□




Unshielded Models

E2E□□MD□□




■ LEAKAGE CURRENT (TYPICAL)

E2E□X□□D□□




■ RESIDUAL OUTPUT VOLTAGE (TYPICAL)

E2E□X□□D□□




■ SENSING DISTANCE VS. SENSING OBJECT (TYPICAL)


E2E-X2D□




E2E-X3D□□




E2E-X7D□□




E2E-X10D□




E2E-X4MD□□




E2E-X8MD□□



E2E-X14MD□




E2E-X20MD□



Dimensions

■ DRAWING LOCATOR

Type			Part number	Figure number
Pre-wired	Shielded	M8	E2E□X2D□□	1
		M12	E2E□X3D□□	3
		M18	E2E□X7D□□	5
		M30	E2E□X10D□	7
	Unshielded	M8	E2E□X4MD□□	2
		M12	E2E□X8MD□□	4
		M18	E2E□X14MD□	6
		M30	E2E□X20MD□□	8
4-Pin connector (M12)	Shielded	M8	E2E□X2D□□:M1G□	9
		M12	E2E□X3D□□:M1G□	11
		M18	E2E□X7D□□:M1G□	13
		M30	E2E□X10D□□:M1G□	15
	Unshielded	M8	E2E□X4MD□□:M1G□	10
		M12	E2E□X8MD□□:M1G□	12
		M18	E2E□X14MD□□:M1G□	14
		M30	E2E□X20MD□□:M1G□	16
M8 connector	Shielded	M8	E2E□X2D□□:M8G□	17
	Unshielded		E2E□X4MD□□:M8G□	18
Pigtail connector	Shielded	M12	E2E□X3D1□M1GJ□	19
		M18	E2E□X7D1□M1GJ□	21
		M30	E2E□X10D1□M1GJ□	23
	Unshielded	M12	E2E□X8MD1□M1GJ□	20
		M18	E2E□X14MD1□M1GJ□	22
		M30	E2E□X20MD1□M1GJ□	24
Pigtail connector, no polarity	Shielded	M12	E2E□X3D1□M1J□	25
		M18	E2E□X7D1□M1J□	26
		M30	E2E□X10D1□M1J□	27

E2E-X2D 

Unit: mm (inch)

Fig. 7:

E2E-X10D




Fig. 8:

E2E-20MD


Connector Models
(Shielded)Connector Models
(Unshielded)

Fig. 9:

E2E-X2D-M1G




Fig. 10:

E2E-X4MD-M1G




Fig. 11:

E2E-X3D-M1G





Fig. 12:

E2E-X8MD-M1G



Connector Models (Shielded), continued

Fig. 13 E2E-X7D□-M1G





Fig. 15: E2E-X10D□-M1G



M8 Connector Models (Shielded)

Fig. 17: E2E-X2D□-M3G




Fig. 14: E2E-X14MD□-M1G






Fig. 16: E2E-X20MD□-M1G



M8 Connector Models (Unshielded)

Fig. 18: E2E-X4MD□-M3G



Unit: mm (inch)

PIGTAIL CONNECTOR

Fig. 19:

E2E[X3D1]M1GJ
E2E[X3D1]M1UT




Fig. 20:

E2E[X8MD1]M1GJ




Fig. 21:

E2E[X7D1]M1GJ
E2E[X7D1]M1UT





Fig. 22:

E2E[X14MD1]M1GJ



Pigtail Connector Models, continued

Fig. 23: E2E-X10D1-M1GJ
E2E-X10D1-M1J-T






Fig. 24: E2E-X20MD1-M1GJ



Mounting Holes














Dimensions	M8	M12	M18	M30
F (mm)	8.5 ^{+0.5} / ₀ dia.	12.5 ^{+0.5} / ₀ dia.	18.5 ^{+0.5} / ₀ dia.	30.5 ^{+0.5} / ₀ dia.

Connection

PIN ARRANGEMENTS

E2E-X□D□-M□□DC2-wire Models

Connector	Self-diagnostic output	Output configuration	Applicable models	Pin arrangement
M12 Micro Change®	No	NO	E2E-X□D1-M1G□□ (See Note.)	  <p>Note: Terminals 2 and 3 are not used.</p>
			E2E-X□D1-M1J-T	  <p>Note: 1. Terminals 1 and 2 are not used. 2. Terminals 3 and 4 have no polarity.</p>
			E2E-X□D1-M1□□	  <p>Note: Terminals 1 and 2 are not used.</p>
		NC	E2E-X□D2-M1G (See Note.)	  <p>Note: Terminals 3 and 4 are not used.</p>
			E2E-X□D2-M1□□	  <p>Note: Terminals 1 and 4 are not used.</p>
	Yes	NO	E2E-X□D1S-M1	<p>(Control output)</p>  <p>Note: Terminal 1 is not used.</p>

Note: Pin arrangements conform to IEC standards.

(This table continues on the next page.)


■ PIN ARRANGEMENT (CONTINUED)

Connector	Self-diagnostic output	Output configuration	Applicable models	Pin arrangement
M8 Nano Change®	No	NO	E2E-X□D1□M3G	 Note: Terminals 2 and 3 are not used.
		NC	E2E-X□D2□M3G	 Note: Terminals 3 and 4 are not used.


Precautions

■ MOUNTING


Do not tighten the nut with excessive force. A washer must be used with the nut.



Shielded Model



Unshielded Model




Note: The table above right shows the tightening torques for part A and part B nuts. In the previous examples, the nut is on the sensor head side (part B) and hence the tightening torque for part B applies. If this nut is in part A, the tightening torque for part A applies instead.

Type		Part A		Part B
		Length	Torque	Torque
M8	Shielded	9 mm	9 N • m (90 kgf • cm)	12 N • m (120 kgf • cm)
	Unshielded	3 mm		
M12		30 N • m (310 kgf • cm)		
M18		70 N • m (710 kgf • cm)		
M30		180 N • m (1,800 kgf • cm)		

■ EFFECTS OF SURROUNDING METAL


When mounting the E2E within a metal panel, ensure that the clearances given in the following table are maintained. Failure to maintain these distances may cause deterioration in the performance of the sensor.



Type		Dimension	M8	M12	M18	M30
E2E□□□□□ DC 2-wire	Shielded	ℓ	0 mm	0 mm	0 mm	0 mm
		d	8 mm	12 mm	18 mm	30 mm
		D	0 mm	0 mm	0 mm	0 mm
		m	4.5 mm	8 mm	20 mm	40 mm
		n	12 mm	18 mm	27 mm	45 mm
	Unshielded	ℓ	12 mm	15 mm	22 mm	30 mm
		d	24 mm	40 mm	70 mm	90 mm
		D	12 mm	15 mm	22 mm	30 mm
		m	8 mm	20 mm	40 mm	70 mm
		n	24 mm	40 mm	70 mm	90 mm

■ MUTUAL INTERFERENCE

When installing two or more Sensors face to face or side by side, ensure that the minimum distances given in the following table are maintained.



Type		Dimension	M8	M12	M18	M30
E2E□□□□□ DC 2-wire	Shielded	A	20 mm	30 (20) mm	50 (30) mm	100 (50) mm
		B	15 mm	20 (12) mm	35 (18) mm	70 (35) mm
	Unshielded	A	80 mm	120 (60) mm	200 (100) mm	300 (100) mm
		B	60 mm	100 (50) mm	110 (60) mm	200 (100) mm

Note: The figures in parentheses refer to Sensors operating at different frequencies.

■ INSTALLATION

Power Reset Time

The Proximity Sensor is ready to operate within 100 ms after power is supplied. If power supplies are connected to the Proximity Sensor and load respectively, be sure to supply power to the Proximity Sensor before supplying power to the load.

Power OFF

The Proximity Sensor may output a pulse signal when it is turned off. Therefore, it is recommended to turn off the load before turning off the Proximity Sensor.

Power Supply Transformer

When using a DC power supply, make sure that the DC power supply has an insulated transformer. Do not use a DC power supply with an auto-transformer.

Sensing Object

Metal Coating:

The sensing distances of the Proximity Sensor vary with the metal coating on sensing objects.

■ WIRING

High-tension Lines

Wiring through Metal Conduit

If there is a power or high-tension line near the cable of the Proximity Sensor, wire the cable through an independent metal conduit to prevent against Proximity Sensor damage or malfunctioning.

■ CONNECTING LOAD TO DC 2-WIRE SENSOR

Refer to the following before using AC or DC 2-wire Proximity Sensors.

Surge Protection

Although the Proximity Sensor has a surge absorption circuit, if there is any machine that has a large surge current (e.g., a motor or welding machine) near the Proximity Sensor, connect a surge absorber to the machine.


Leakage Current

When it is OFF, the Proximity Sensor has leakage current. Refer to Leakage Current Characteristics. In this case, the load is imposed with a small voltage and the load may not be reset. Before using the Proximity Sensor, make sure that this voltage is less than the load reset voltage.

Countermeasures Against Leakage Current

DC 2-wire Models

Connect a bleeder resistor as the bypass for the leakage current so that the current flowing into the load will be less than the load reset current.



Cable Traction Force

Do not pull cable with the traction forces exceeding the following.

Diameter	Traction force
4 mm dia. max.	30 N max.
4 mm dia. min.	50 N max.

■ MOUNTING

The Proximity Sensor must not be subjected to excessive shock with a hammer when it is installed, otherwise the Proximity Sensor may be damaged or lose its water-resistance.

■ ENVIRONMENT

Water Resistance

Do not use the Proximity Sensor underwater, outdoors, or in the rain.

Operating Environment

Use the Proximity Sensor within its operating ambient temperature range and do not use the Proximity Sensor outdoors, in order to maintain its reliability and life expectancy. Although the Proximity Sensor is water resistant, a cover to protect the Proximity Sensor from water or water soluble machining oil is recommended to maintain its reliability and life expectancy. Do not use the Proximity Sensor in an environment with chemical gas (e.g., strong alkaline or acid gasses including nitric, chromic, and concentrated sulfuric acid gasses).

Refer to the following to calculate the bleeder resistance and the allowable power of the bleeder resistor.

$$R \leq V_S / (i_R - i_{OFF}) \text{ (k}\Omega\text{)}$$

$$P > V_S^2 / R \text{ (mW)}$$

P: The allowable power of the bleeder resistor. (The actual power capacity of the bleeder resistor must be at least a few times as large as the allowable power of the bleeder resistor.)

i_R : Leakage current of Sensors (mA)

i_{OFF} : Release current of load (mA)

The following resistors are recommended.

12 VDC (supply voltage): A resistor with a resistance of 15 k Ω maximum and an allowable power of 450 mW minimum
24 VDC (supply voltage): A resistor with a resistance of 30 k Ω maximum and an allowable power of 0.1 W minimum

Inrush Current

A load that has a large inrush current (e.g., a lamp or motor) will damage the Proximity Sensor, in which case connect the load to the Proximity Sensor through a relay.

NOTE: DIMENSIONS SHOWN ARE IN MILLIMETERS. To convert millimeters to inches divide by 25.4.

OMRON[®]
OMRON ELECTRONICS LLC
One East Commerce Drive
Schaumburg, IL 60173
1-800-55-OMRON

OMRON ON-LINE
Global - <http://www.omron.com>
USA - <http://www.omron.com/oei>
Canada - <http://www.omron.com/oci>

OMRON CANADA, INC.
885 Milner Avenue
Scarborough, Ontario M1B 5V8
416-286-6465