

2SD1263, 2SD1263A

Silicon NPN triple diffusion planar type


For power amplification

■ Features

- High collector to base voltage V_{CBO}
- Full-pack package which can be installed to the heat sink with one screw

■ Absolute Maximum Ratings ($T_C=25^\circ\text{C}$)

Parameter		Symbol	Ratings	Unit
Collector to base voltage	2SD1263	V_{CBO}	350	V
	2SD1263A		400	
Collector to emitter voltage	2SD1263	V_{CEO}	250	V
	2SD1263A		300	
Emitter to base voltage		V_{EBO}	5	V
Peak collector current		I_{CP}	1.5	A
Collector current		I_C	0.75	A
Collector power dissipation	$T_C=25^{\circ}\text{C}$	P_C	35	W
	$T_a=25^{\circ}\text{C}$		2	
Junction temperature		T_j	150	$^{\circ}\text{C}$
Storage temperature		T_{stg}	-55 to +150	$^{\circ}\text{C}$









■ Electrical Characteristics ($T_C=25^\circ\text{C}$)


Parameter	Symbol	Conditions	min	typ	max	Unit
Collector cutoff current	I_{CES}	$V_{CE} = 350\text{V}, V_{BE} = 0$			1	mA
2SD1263A		$V_{CE} = 400\text{V}, V_{BE} = 0$			1	
Collector cutoff current	I_{CEO}	$V_{CE} = 150\text{V}, I_B = 0$			1	mA
2SD1263A		$V_{CE} = 200\text{V}, I_B = 0$			1	
Emitter cutoff current	I_{EBO}	$V_{EB} = 5\text{V}, I_C = 0$			1	mA
Collector to emitter voltage	V_{CEO}	$I_C = 30\text{mA}, I_B = 0$	250			V
2SD1263A			300			
Forward current transfer ratio	h_{FE1}^*	$V_{CE} = 10\text{V}, I_C = 0.3\text{A}$	70		250	
	h_{FE2}	$V_{CE} = 10\text{V}, I_C = 1\text{A}$	10			
Base to emitter voltage	V_{BE}	$V_{CE} = 10\text{V}, I_C = 1\text{A}$			1.5	V
Collector to emitter saturation voltage	$V_{CE(sat)}$	$I_C = 1\text{A}, I_B = 0.2\text{A}$			1	V
Transition frequency	f_T	$V_{CE} = 5\text{V}, I_C = 0.5\text{A}, f = 10\text{MHz}$		30		MHz
Turn-on time	t_{on}	$I_C = 1\text{A}, I_{B1} = 0.1\text{A}, I_{B2} = -0.1\text{A}, V_{CC} = 50\text{V}$		0.5		μs
Storage time	t_{stg}			2		μs
Fall time	t_f			0.5		μs

* h_{FE1} Rank classification

Rank	Q	P
h_{FE1}	70 to 150	120 to 250

$P_C - T_a$  $I_C - V_{CE}$  $I_C - V_{BE}$  $V_{CE(sat)} - I_C$  $h_{FE} - I_C$  $f_T - I_C$ 

Area of safe operation (ASO)

 $R_{th(t)} - t$ 